





AN1004 – Extraction of Log Data from Accu-Gold



- Start Accu-Gold 2
- In the “Accu-Gold 2 Start Menu” click on “Continue”:



- Click on the “Accu-Gold 2” menu in the upper left corner:






AN1004 – Extraction of Log Data from Accu-Gold



- Click on the menu entry “Help”
- Click on the menu entry “About”



- Click on “Export log...”
- Save the “Accu-Gold_Logs.zip” where you can find it again then email to Cust_sup@Radcal.com.